Mr./Mrs/Ms:						Model:							Reg.No:				
Invoice/Job no:				_ Odd	Odometer reading:							V.I.N:					
Service type:	Α	В	Α	С	Α	В	Α	С	Α	В	Α	С	Α	В	Α	С	
Months/,000 km:	6/10	12/20	18/30	24/40	30/50	36/60	42/70	48/80	54/90	60/100	66/110	72/120	78/130	84/140	90/150	96/160	
Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *																	



RANGE ROVER

(ALL MODELS 99 MY ON)

MAINTENANCE CHECK SHEET

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost	Check -	After the checking procedure,	cleaning, adjusting,	repairing or replacing	g is subject to extra labour	and material cost.
--	---------	-------------------------------	----------------------	------------------------	------------------------------	--------------------

A B C	VEHICLE INTERIOR	A B	C UNDER BONNET		
1	Note: Petrol models do not require service "A" after 12 months/20,000 km.	35.	Check battery condition		
2.	Check condition and security of seats and seat belts		80k Flush diesel intercooler eler	nent	
3	Check operation of all lamps, horns and warning indicators	00.	MAIN SERVICE (UNDER V		
4	Check operation of front/rear wipers and washers and condition of wiper blades		Renew engine oil and filter	- ,	
5	Check operation of handbrake	37. 📖 📖			
6.	Replace alarm handset batteries	38.	Renew manual gearbox oil	a a what y ail	
0.	VEHICLE EXTERIOR	39.	Check and top up manual g	earbox on ion filter - First 40,000 km only	
	Annual corrosion/cosmetic inspection - Only on vehicles sold after 28/11/98	40.	Renew automatic transmiss		
/. L L E	Depressurise air suspension and replace compressor intake and exhaust filters	41.	Renew transfer box oil	ion on	
8.	Remove/refit air reservoir drain plug (if evidence of water in system, replace dryer)	42.	Check and top up transfer b	ov oil	
9.	Repressurise air suspension system	43.		il - First 10,000km only then 160,000km	
10.	Check/adjust headlamp alignment		Check and top up front and	•	
11.	Remove road wheels	45.	Lubricate propeller shaft un		
12.		46.		· ·	ofina
13. 🔲 📖 📖	Check tyre pressures, condition and tread depth.	47	leaks and corrosion.	clutch pipes, unions, and electrical harnesses for ch	anng,
	LHF RHF RHR LHR Spare	40		ower steering and suspension systems hydraulic pip	nes and
14.	Inspect brake pads for wear , calipers for leaks and discs for condition	48. 📖 📖	unions for chafing and corre		700 and
15.	Inspect road wheel speed sensor harness for damage	49.		ngine, Gearbox, Transfer box and Axles	
16. 80k	Renew fuel filter element (V8) To VIN WA410481	50.	Check exhaust system for le		
17. 🔲 🔲 🗀	Renew fuel filter element <i>Every 30,000 km/18 months (Diesel)</i>	51.		front and rear axle fixings and suspension fixings.	
18.	Drain fuel sedimenter (<i>Diesel only</i>)	52.		fixings and condition of ball joints and dust covers	
19.	Refit road wheels to original hub position (Use anti-seize compound on spigot bore)	53.		and springs for security and damage	
20.	Visually check intercooler/radiator for external obstructions and fan blades for damage	54.		ght sensors and harness assembly for leakage and	damage
21.	Check operation and Lubricate door locks, hinges, door checks, bonnet catch & fuel flap	55.	Check security of towing bra		
22.	Check sunroof drain tubes	56.		ed, interrogate that system using TestBook and repo	ort
	UNDER BONNET	56.	findings	sa, menogate that eyelem demig 1 cetzeen and 1 epe	
23. 60k 120k	Renew anti-freeze	57.	Carry out road or roller test	(see WARNING over page)	
	Renew brake fluid	58.	Endorse service record		
25.	Check cooling, intercooler and heating systems for leaks, hoses and oil pipes for	59.	Report any unusual feature	s of vehicle condition and additional work required	
	security and condition . Top up as required			vehicles operating under normal driving, road and climatic condi	
26. 160l	Renew charcoal canister, check evaporative loss system and fuel filler flap seal (V8)			ct to stop/start operation, extremes of temperature, dusty condition	ns, off roa
27. 120	k Renew spark plugs	driving or frequent	towing of trailers.		
28.	Renew air cleaner element and clean drain hole (V8)	Service check cor	npleted and service portfolio book endorsed		
29.	Renew air cleaner element and clean drain hole (Diesel)				
30.	Renew pollen filters	Name:	Signature:	Date:	
31.	Check condition of ancillary driving belt				
32.	Renew ancillary driving belt				
33.	Check condition of steering intermediate shaft				
34	Check/top up brake, PAS and clutch fluid levels and screen washer reservoirs				

04/00 LRL0354ENX

WARNING:

Two wheel roller tests must not be carried out. Four wheel roller tests must be restricted to 5km/h.

IMPORTANT

OIL CHANGE DIESEL ENGINES

If the vehicle is operated on fuel with a high sulphur content (over 1%) the oil change intervals must not exceed 10,000 km

VEHICLES FITTED WITH SUPPLEMENTARY RESTRAINT SYSTEMS

The seatbelt pre-tensioners (where fitted) and air bags must be replaced every TEN YEARS

Side air bags must be replaced every FIFTEEN YEARS

IT IS RECOMMENDED THAT:

At 120,000 km or every six years, whichever is the sooner, all hydraulic brake fluid seal and hoses should be renewed.

All working surfaces of the caliper cylinders should be examined and renewed where necessary.

Vehicles used extensively in arduous/off road conditions - check the road wheel speed sensors, brake pads and calipers for abrasive wear at 1500 km intervals

Air suspension vehicles used extensively in arduous/off road conditions will require the compressor inlet and exhaust filters to be replaced at more regular intervals.

When the vehicle is used in dusty or field conditions or deep wading, frequent attention to the air cleaner may be required.

When the vehicle is used in areas where fuel quality is poor, more frequent draining of the fuel filter/sedimentor may be required.

GLOSSARY

LUBRICATION SERVICE "A" = The lubrication service is carried out between main services, the first at 6 months or 10,000 km, whichever occurs first, and then at every subsequent 12 months or 20,000 km, i.e. 30,000 km, 50,000 km etc.

NOTE: The lubrication service is only applicable to Diesel AFTER the first occurrence.

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 20,000 km intervals, whichever occurs first.

Main Service "B"is applicable at 12 months/20,000 km, 36 months/60,000 km, 60 months/100,000 km 84 months/140,000 km and so on.

Main Service "C"is applicable at 24 months/40,000 km, 48 months/80,000 km, 72 months/120,000 km, 96 months/160,000 km, and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 100k (This indicates that this item is only applicable every 60 months/100,000 km)